

KEEPSAFE™ ENERGY CAP

INSTRUCTIONS

TO ATTACH:

1. Place raised knob against the center of the detacher to open lock.



2. Position Energy Cap on top of can with open portion facing down.



3. Gently close by squeezing two sides together until you hear the Energy Cap click audibly.



TO DETACH:

1. Place raised knob against the center of the detacher.



2. Energy Cap should unlock and slightly open. If lock does not disengage while in detacher, squeeze gently.



3. Gently pull cap open if needed. Lift or remove from top of can.

